


Ambi-Dry Verge Bag Contents

- 10 Ambi-Dry Verge Units
- 10 Batten End Clips
- 10 Stainless Steel Nails
65mm x 3.35mm dia
- 20 Stainless Steel Nails
20mm x 2.65mm


Eaves/Ridge Pack Contents
(available separately)

Product Code 9680

- 1 Eaves Closure Unit
- 1 Ambi-Dry Eaves Clip
- 1 Ridge Comb Unit
- 2 Stainless Steel Annular Ring Shanked Nails
55mm x 2.65mm dia
- 2 Stainless Steel Pan Head Self-Tapping Screws
3/4" x 8 Gauge.




1. Felt and batten the roof, carrying the underlay over the full width of the gable and extending the tiling battens beyond brickwork, bargeboard or gable ladder by 45mm. Ensure all battens project by the same distance to achieve a straight verge line.



2. Using the 20 x 2.65mm dia. nails provided, fix a Batten End Clip to each tiling batten.

Fascia Fixing of Eaves Closure Unit




LEFT HAND

RIGHT HAND


3. Taking an Eaves/Ridge Pack, pass the "L" shaped clip through the "T" shaped slot in the Eaves Closure Unit in direction of the arrow shown and turn to suit left or right hand verge.

3a. Alternatively the Eaves Closure Unit can be fixed directly to the bargeboard, through the two most appropriate holes in the Eaves Closure Unit, using the two screws provided.




4. Using the nails and clip provided in the Eaves/Ridge Pack, fix the Eaves Closure Unit to the fascia as shown. At this stage one of two approaches may be adopted:


- i) Lay all tiles and fix the Ambi-Dry Verge Units afterwards.
- ii) Fix Ambi-Dry Verge Units as the tiles are laid. In either case the procedure is as shown from 5 onwards.




5. Set all tile courses 5mm back from the batten end on each verge. Ensure that the eaves tile is fully inserted into the Eaves Closure Unit. The interlocks of left hand verge tiles must be removed.







6. Depending on the hand of the verge, prepare the Ambi-Dry Verge Units by snapping out the relevant section. Picture above shows a right hand Ambi-Dry Verge Unit being prepared.



7. Clip the first Ambi-Dry Verge Unit over the Eaves Closure Unit. Slide the Ambi-Dry Verge Unit in the direction of the ridge until the tail coincides with the tail of the tile.



8. Ensuring contact with the head of a tile, nail the Ambi-Dry Verge Unit into the Batten End Clip. Nail through the most convenient hole using the 65 x 3.35mm nail provided.



Verge Maximum Pitch Information

Duo Pitch Roof		
dry fix		60.0°
mortar		72.7°
Mono Pitch Roof		
dry fix		47.5°
mortar		80.0°

There is no maximum pitch on lean-to roofs or where lead roll details are used.